**Exploring Coffee Secrets** 



**BC01 Series**Coffee machine instructions

# Content

1	Intro	duction4
	1.1	Welcome4
	1.2	About the insturction
	1.3	Description
	1.4	Manufacture instruction5
2	Safe	ety6
	2.1	Purpose6
	2.2	Sately instruction
		2.2.1 Consumer's risk
		2.2.2 Machine's risk
		2.2.3 Dangers of cleaing agents9
		2.2.4 Hygiene regulation
	_	
3	Proc	luct description
	3.1	Product13
	3.2	Technical data14
		3.2.1 Capacity14
		3.2.2 Technical sheet
	3.3	Accessories15
4	Insta	allation and Testing
	4.1	Prerequisites15
		4.1.1 Installation Site
		4.1.2 Weather condition
		4.1.3 Electronic condition

# This instruction is for BC01、BC01-S.

There is difference between picture and products, because of the upgrading of products. Please refer to the actural products.

		4.1.4 Water condition.       17         4.1.5 Milk drink requests.       18
	4.2	Installation.       18         4.2.1 Coffee machine.       18         4.2.2 Coffee bean hopper, powder hopper installation.       18
	4.3	Connection.194.3.1Water inlet tube connection.194.3.2Waste water tube connection.204.3.3Install milk cleaning waste waterpipe.21
	4.4	Power.         21           4.4.1 Coffee machine power.         21
5	Initia	ıl working22
	5.1	Filling.         22           5.1.1 Coffee beans hopper filling.         22
	5.2	Power on the coffee machine22
	5.3	Default Setting
	5.4	Grinding settings.245.4.1 Grinding level setting.255.4.2 Calibration of milling powder quantity.27
	5.5	Dumping
	5.6	Power off
6	Drin	k making32
	6.1	Coffee drink
7	Rins	e and maintenance34
	7.1	Cleaing schedule34

7.2	Quick	ccleaning35
	7.2.1	System warm-up
	7.2.2	Automatic Quick cleaning Setting
7.3	Deep	cleaning37
	7.3.1	Brewer deep clean
7.4	Manu	al cleaning37
	7.4.1	Beverage outlet Cleaning
	7.4.2	Cleaning inside the machine
	7.4.3	Brewing system disassembly and cleaning
	7.4.4	Beans, powder bin cleaning
7.5	Desc	aling
7.6	Stora	ge42
Res	ponsi	bility and warranty
8.1	User'	s responsibility43
8.2	Warr	anty and compensation43
Dail	y use	and maintance

# 1 Introduction

#### 1.1 Welcome

- This model is the latest fully-automatic coffee machine which is also core patented.
- This instruction introduce how to use and clean this machine. We will not responsible for the lost for the damaging, in case of you did now follow up our instructions. If you need to know more details, please contact with our customer service department.
- This instruction show you how to use and clean the machine. Please use the machine under instructions and keep the instructions for further reading.

#### 1. 2 About these instructions

- These instructions are included with the equipment. Always keep these instructions in legible condition at the place of use of the product.
- Modifications to these instructions due to technical advancements reserved. Reprints, translations and reproductions in any form, including exrpts, require written approval from the publisher. The copyright is held by the manufacturer.
- This instruction is for: BC01 Series.

## 1.3 Machine Description

- This fully automatic coffee machine is used to make black coffee, milk coffee, powder product. To make sure it meet the demand of large quantity daily cups, the machine is used for the restaurant, office and other commercial sites.
- The following products can be dispensed depending on the machine equipment: Coffee, milk coffee powder drink and milky products.

- The housing consists of aluminum and high quality plastic. The design of this machine and all accessories permits the following operator requirements to be observed:
- Accident prevention regulations for electrical safety in the commercial area;
- The machine has a touch screen for operation.

#### 1.4 Manufacture information

Suzhou Dr.Coffee System Technology Co.,Ltd

#55 Taishan Road, New District, Suzhou City, Jiangsu, China

E-mail: info@dr-coffee.com

Hotline: 400-8977-711

www.dr-coffee.com

# 2 Safety

Safety is one of our most important features. To make sure that safety device remines useful, you must follow up with the instruction.

### 2.1 Purpose

This machine and all accessories are intended for the following operating modes:

- Usage of the personnel authorized by the manufacturer;
- Supervised self-service operation (self-service);
- With fixed water connection;
- Pressure-free operation via freshwater and barrel water;
- Permanent installation within dry, enclosed room.

This machine and all accessories are not intended for the following operating modes:


- Areas with high percentage humidity (flash steam area) or outdoors.
- On board of vehicles or in mobile applications (please check with the manufacturer).

# 2. 2 Safety Instructions

#### 2. 2. 1 Customer's risk

- You may get hurt if instructions are not well followed up. Please must observe the following points:
  - Please read the instructions carefully before you using it;
  - Don't operate it, if the machine is not running normal or damage;
  - Changing the safety device is not permitted;
  - Touching the high temperature components is not permitted;

- This equipment can be used by children of 8 years and above, and by persons with reduced physical, sensory or mental abilities or of a lesser level of experience and knowledge when they are supervised or have been trained in the safe use of the equipment;
- Children are not allowed to play with the equipment, Children are not permitted to cleaning and maintenance machine;
- Machine is installed at obvious site;
- Self-service use and operation should be supervised by trained personel. To ensure compliance with maintenance regulations and to resolve usage issue at any time.



- Electrical equipment should only be carried out by trained personne;
- The machine much be connected with fuse-protected circuit (Connection by selective leakage protection);
- Observe the corresponding low voltage and local and regional safety regulations;
- The connection must obey the regulation to avoid the electronic;
- The supply voltage must match the details on the nameplate;
- Don't touch live parts.



Warning: It must disconnect power supply before repairing.



Warning:Replacing a power cord not provided by our company may present a risk of fire or electric shock.



Warning: Be careful with the drinks additives and residues case allergies  $_{\circ}$ 

Please must observe the following points:

 Check the additives in case of allergy listed on the display under selfservice operation;





- In self-service applications, look for allergy-causing add-on products that professionals may use.
- Scalding Hazard: Risk of scalding in areas where beverages, hot water and steam are made. Do not put your hands under the spout during preparation or cleaning.
- Scalding Hazard: High temperature may be present at the spout and the brewing unit. Only allow access to handles pre-designed for production. Clean the brewing unit only after the machine has cooled down.
- Crush Caution: There is a risk of crushing by touching any moving parts. Do not reach into the coffee bean hopper, powder hopper or opening of the brewing unit when the machine is switched on.

#### 2.2.2 Hazards to Machines



WARNING: Incorrect use of the coffee machine may result in damage or contamination of the machine.

Please observe the following points:

- Install a limescale filter if the carbonate hardness in the water exceeds 5°dKH, otherwise the coffee machine will be damaged by calcification;
- For safety reasons, always pay attention to closing the main water valve (coffee machine with a fixed water connection) after shutting down and turning off the main switch or pulling out the plug;
- Please abide by the relevant low-voltage directives and/or national and local safety rules and regulations;
- Please ensure that the water source is normal before starting the machine, otherwise the pump will be idling;
- Dr. Coffee recommends (at the time of delivery and installation) to install a check valve in the water pipe to avoid water seepage hazard when the hose is ruptured;

- The coffee machine must be cleaned and then restarted after a prolonged shutdown (such as a corporate vacation);
- Protect the coffee machine from weather (frost, humidity, etc.)
- Troubleshooting can only be done by professional technicians;
- Please use original accessories from Dr. Ka company;
- For external visible damage or leakage, please contact customer service immediately for replacement or repair;
- Do not rinse the machine with water or use steam cleaners:
- Do not place the machine on surfaces that may be sprayed with water;
- Only coffee beans can be placed in the coffee bean bin, and only special instant powder can be placed in the powder bin;
- Freeze-dried coffee must not be used, as this will cause the brewing unit to stick;
- If the coffee machine and its accessories are transported at a
  temperature below 10°C, the coffee machine and its accessories
  must be left at room temperature for three hours after transport before
  they are plugged in and turned on. Failure to observe this may result
  in a risk of short circuits due to condensation or damage to electrical
  components;
- Always use a new hose set (drinking water/wastewater hose) supplied with the machine, never use an old hose.

#### 2.2.3 Dangers of cleaning agents



Use: Danger of poisoning by ingesting cleaning agents! Please observe the following points:

- Cleaner storage should be kept away from children and unauthorized persons.
- Cleaning agents should not be ingested.
- Do not mix cleaners with other chemicals or acids.
- Never add cleaning agents to the drinking water tank.
- Cleaners and decalcifiers should only be used for their intended purpose (see label).
- Do not eat or drink while using the cleaner.

- Good ventilation and exhaust must be ensured when using cleaning agents.
- Wear protective gloves when working with cleaning agents.
- Wash hands thoroughly and immediately after using cleanser.



#### Storage: Be sure to observe the following points:

- Store out of the reach of children and unauthorized persons.
- When storing, pay attention to heat, light and moisture.
- Separated from acidic substances.
- Store only in original packaging.
- Keep cleaning agents separate.
- Do not store with food or drink.
- Exhaust Disposal: If the product is not available, the cleaning agent and its receptacle must be disposed of in accordance with local laws.
- Emergency Advice: Ask the cleaning agent manufacturer (see detergent label) for the telephone number of the Emergency Advice (Toxicology Advice Center).

#### 2.2.4 Health rules



Water: Improper use of water can be a health hazard! Please observe the following points:

- The water must be clean and free from contamination.
- Do not add corrosive water to the coffee machine.
- The carbonate hardness must not exceed 5~6 °dKH (German carbonate hardness) or 8.9~10.7 °fKH (French carbonate hardness).
- The total hardness value must always be higher than the carbonate hardness.
- The minimum carbonate hardness is 5 °dKH or 8.9 °fKH.

- The maximum chlorine content is 100 mg per liter.
- Ph value 6.5~7 (pH neutral).
- Machines with drinking water tanks (internal & external):
  - Fill the drinking water tank with clean water every day;
  - The drinking water tank must be thoroughly cleaned before adding water.



#### Coffee: Incorrect use of coffee can be detrimental to your health! Be sure to observe the following points:

- Check for damage before unpacking.
- Do not add more than one day's worth of coffee beans.
- Close the coffee bean compartment cover immediately after adding coffee beans.
- Coffee should be stored in a dry, cool and dark place.
- Coffee should be stored separately from detergents.
- The oldest product purchased should be used first ("early in, early out" principle).
- Please use it up within the warranty period.
- The package should be well sealed after opening to keep the product in the package fresh and prevent it from contamination.




# Milk: It will harmful for the healthy with incorrect operation of milk! Be sure to observe the following points:


- Don't use raw milk.
- Only pasteurized and heat treated milk.
- Only homogenize milk.
- Please use the cold milk which temperature is around 4-10°C.
- Wear gloves during milk treatment.
- Only milk from original package.
- Filling milk into original package is not permitted. Clean the milk container before filling.
- Check the package.
- The filling capacity of milk is no more than the daily usage.



- Close the cover of milk container and cooler after filling (Inside / Outside).
- Keep the milk in dry, cold and enclosed room.(Highest temperature
- Use fresh milk.
- Use beans during the shelf-life.
- Seal package after opening it, to prevent it from pollution.

# Machine description





### 3. 2 Technical Parameters

#### 3. 2. 1 Output capacity

Cups per hour based on DIN18873-2:

Daily output	300 Cups			
Cups per hour	Single	Double		
Espresso	156	210		
Ristretto	160	225		
Coffee bean hopper capacity	Approx. 2 * 1200 g			
Grounds container capacity	About 100 pcs (Base on 10g/Shot)			

### 3. 2. 2 Specification parameters

Coffee machine	220-240V~ 50/60Hz 2900W			
Connection tube set	G3/4'change into G3/8'length1.5M metal tube			
Connection water pressure	80-600kPa (0.08-0.6MPa)			
Coffee machine W*D*H	34 * 54 * 83 cm			
Coffee machine N.W	39 kg			

#### 3.3 Default accessories

The fully automatic coffee machine is supplied with the following accessories:


Beans hopper	x2 Pcs	Waste water connection	x1 Pcs
Cable	x1 Pcs	Water inlet pipe	x1 Set
Quick start guide	x1 Pcs	Cleaning Box	x1 Pcs
Dete-rgent inlet pipe	x1 Pcs		

# 4 Installation and testing

Professionally trained personnel can perform the following operations.

# 4.1 Placement requirements

#### 4.1.1 location



- The installation surface must be stable and flat, and will not deform under the condition of bearing the weight of the coffee machine;
- Do not place it near a hot surface or heat source;
- The coffee machine is located so that trained personnel can look after it at all times;
- The distance between the energy interface specified on the site installation drawing and the machine location shall not exceed 1m.
- Reserve some space for maintenance work and operation:
   ·废液管不可受压迫或曲挠;废液管末端不可淹没入废液收集器液面以下;
   ·Leave enough space above to fill the coffee beans;

- ·Keep a minimum distance of 5cm between the back of the device and the wall (air circulation);
- ·Observe valid regulations on local cooking techniques.

#### 4. 1. 2 Climate conditions

- The following climatic conditions are suitable for placing the coffee machine. Failure to guarantee these conditions may damage the machine. Be sure to abide by the following conditions:
  - Ambient temperature maintained at +10°C to +35°C (50°F to 96°F)
  - Relative air humidity up to 80 % rF;
  - The coffee machine is designed for indoor use only. Do not use outdoors, protected from weather (rain, snow, frost)!
- Low temperature storage requirements:
  - If the coffee machine in normal use needs to be stored or transported, when the ambient temperature is lower than 0°C, the waterway must be emptied first.

#### 4. 1. 3 Power conditions

- The electrical connection must be made in accordance with the relevant regulations of the country in which it is used. The voltage at the installation site must match the voltage given on the nameplate.
- Warning electric shock: Danger of electric shock!
  Be sure to observe the following points:
  - It must be protected by a fuse with the amperage value stated on the nameplate!
  - All phases of the equipment must be able to be disconnected from the power grid, and the lines connected to the power line must be reliably grounded;
  - The electrical equipment on site must be connected according to IEC 364 (DIN VDE 0100).

- Do not operate the machine with a damaged power cord. Immediately replace damaged power cords or plugs by professional technical service personnel;
- Dr. Coffee recommends that you do not use extension cables! If an extension cable must be used (minimum cross-section: 1.5 mm²), please observe the manufacturer's data (instruction manual) for the power cord and local regulations;
- Route the power cord so that people cannot trip over it. Do not let the
  power cord pass through sharp corners or hang in the air, and do not
  pinch cables. In addition, the cables must not be placed over high
  temperature objects and must be protected from oils and aggressive
  cleaning agents;
- Do not lift or pull on the device by the power cord. Do not pull the plug out of the socket by pulling on the power cord. Never touch the power cord or plug with wet hands! Never insert wet plugs into sockets!

#### 4.1.4 Water conditions

- Poor quality raw materials and poor water quality can damage the machine. Be sure to observe the following points:
  - The water must be clean and contain no more than 100 mg of chlorine per liter;
  - Do not add corrosive water to the coffee machine:
  - Carbonate hardness must not exceed 5~6°dKH (German carbonate hardness) or 8.9~10.7° fKH (French carbonate hardness) and the total hardness value must always be higher than the carbonate hardness.
  - Minimum carbonate hardness is 5°dKH or 8.9°fKH. pH must be between 6.5~7;
  - Be sure to use the new hose kit (clean water/waste hose) supplied with the machine.
- The water supply must be connected in accordance with the current regulations and the regulations of the country in which it is used. If the machine is connected to a newly installed water line, the water line and inlet hose must be rinsed thoroughly to prevent stains from entering the machine.





◆ The coffee machine must be connected to a drinking water line with a throttle valve installed. Fit it to the pressure reducer on the tap (adjusted to 0.3 MPa (3 bar)) via the installed pressure hose and threaded connection G 3/8".

#### 4.1.5 Milk drink requests

- The temperature of milk should be around 4 10 ℃;
- The height of the milk tank or milk box have to be less than 26mm;
- Dr.coffee cooler is suggested to supply with coffee machine.

#### 4.2 Install

#### 4. 2. 1 Coffee Machine

Open the carton, take out machine and spare parts. The machine and all accessory units are only permitted to be installed and stored in frost-free locations.

#### 4. 2. 2 Install coffee bean hopper and powder hopper

Step 1: Insert the key as shown in the figure, turn the key counterclockwise, open the door of the coffee machine, and take out the adjustment handle from the part shown in the figure;



Step 2: Install the coffee bean hopper in place as shown as below picture;



Step 3: Push the handle until it stopping, close the door, then switch off by the key.



√ Coffee bean hopper, powder hopper installation completed.

### 4.3 Connection

#### 4.3.1 Connect the water inlet

Step 1: Connect one end of the water inlet pipe to the water inlet of the coffee machine, and tighten the nut clockwise to fix it;



Step 2: Connect the other end of the water inlet pipe to tap water.



√ Water inlet tube installation completed.

#### 4.3.2 Install the waste pipe

Step 1: Insert the waste pipe into the metal hose clamp and insert it into the joint of the waste water outlet at the bottom of the coffee machine as shown in the figure;



Step 2: Place the outlet of the waste pipe above the waste bucket (or waste pool).



√ Waste water pipe installation completed.

### 4.4 Power source

- The supply voltage must correspond to the description on the nameplate.
- When connecting via the mains plug, it must be ensured that the socket is easily accessible during operation to prevent the plug from being unplugged in the event of a malfunction.
- Due to the large load, this machine and each auxiliary equipment must have a separate socket.

#### 4.4.1 Coffee machine power supply

Step 1: Insert the female end of the power cord of the coffee machine into the socket of the machine;



Step 2: Plug the male end of the coffee maker's power cord into the power outlet.



 $\checkmark$  The power connection of the coffee machine is completed.

# 5 First run

Professionally trained personnel can perform the following operations.

# 5.1 Filling

#### 5.1.1 Fill coffee bean

Open the cover, fill the beans into hopper, then cover the cap.



### 5.2 Power on machine

Switch the key counter clockwise direction, open the door, push the power button, then close the door and switch the key in clockwise direction.



 $\sqrt{}$  Coffee machine power on.

# 5.3 Default setting

Step 1: Click the service menu, input initial value.



Step 2: Click"save", then next step.



Step 3: Machine Starting......




Step 4: Power on complete, machine ready for coffee.




√ Default setting complete.

# 5.4 Grinding settings

Step1: Click on the shortcut menu icon at the top of the screen to enter the shortcut menu interface.



Step2: Click on the 'Service Menu' (password confirmation required);



Step 3: Enter "Engineering Settings" - "Grinding Settings".





### 5. 4. 1 Grinding level setting

Step 1: Choose the grinder.



Step 2: Adjusted the level;



Step 3: Click "Start" to adjust the grinding degree of the coffee machine (after completing the grinding degree gear adjustment, please perform powder (after completing the grinding degree gear adjustment, please perform powder volume calibration before confirming the grinding degree status of the beverage production);



√ Grinding level adjustment completed.

### 5. 4. 2 Calibration of milling powder quantity

Step 1: Go to "Shortcut Menu" - "Service Menu" - "Engineering Settings" - "Grinding System Settings".



Step 2: Remove the slag container and place it on the electronic scale for zeroing and then put it back;



Step 3: Select the bean grinder where you need to adjust the grind;



Step 4: Click the start button for the first powder pickup;



Step 5: When the device finishes taking powder at one time, take out the dregs container and weigh the powder, then clear it and put it back;



Step 6: Enter the value of the powder into the corresponding box and click "Start" for the next powder extraction;



Step 7: Repeat the above steps 5 & 6 to complete the second & third powder collection;



Step 8: Click the Save button to complete the current bean mill grind calibration.



 $\checkmark$  Grinding calibration complete.

## 5.5 Dumping

Step 1: Open the door, remove the grounds container and empty it, then put it back and close the door;



Step 2 (when the appliance is switched on and in use for slag emptying): Follow the interface prompts (the door opening time exceeding 10s triggers the confirmation screen) to correctly click on the "Not emptied"/ "Emptied" slag box option.



√ Dumping completed.

### 5.6 Power off machine

Step 1: Click the icon and shorcut at the top of the screen, then into the menu.



Step 2: Click the option "Power Off" at the bottom of display.



Step 3: The screen pop-up prompts. Are you "power off", click "OK" machine turns to power off mode,click"Back"to cancel this operation, the screen is off but light is still on(press the screen more than 3 seconds to wake up the machine)



Step 4: On power off mode, open the door by the key, push the power button, then lock the door.



√ Coffee machine power off.

# 6 Drink making

The following steps can be operated by end users.

### 6.1 Coffee drink

For example: Make a cup of "Expresso".

Step 1: Click"Espresso", then coffee under processing.



Step 2: The beverage parameter adjustment interface appears. After adjusting and confirming, click "Start Making" to proceed with the beverage (Only work under adjustable mode)



Step 3: Drink under processing...click: Cancel, stop coffee instantly.



√ Coffee drink completed.

# 7 Rinse and maintenance

★The following steps must be operated to the personnel authorized by the manufacturer.

### 7.1 Cleaning schedule

	Dr.coffee commercial coffee machine cleaning schedule						
	Daily	Weekly	Demand	Required	Mandatory	Item	Info
Outable states	0		0			Steam rod clean	▶ P35(7. 2. 1)
Quick clean	0		0			Automatic quick clean	▶ P36 (7. 2. 2)
Deep clean	0			0	•	Brewer deep clean	▶ P37 (7. 3. 1)
						Beverage outlet clean	▶ P37 (7. 4. 1)
Manul clean	0	0				Machine interner clean	▶ P38 (7. 4. 2)
Manul Clean		0				Brewer disassembly and clean	▶ P39 (7. 4. 3)
		0				Bean hopper	▶ P41 (7. 4. 4)
maintenance					•	Descaling	▶ P41 (7.5)
	Interpretation					-	
Daily	Daily Clean at least once per day, possibly more often if needed						
Weekly	Clean at least once per week, possibly more often if needed						
Demand	Clean if required or dirty if required  When the machine shows prompts for cleaning						
Required							
Mandatory	After the machine jumps out of the prompt, it must be cleaned strictly accordance with the requirements to avo irreversible machine damage.						

# 7.2 Quick cleaning

### 7.2.1 System warm-up

Step 1: Click the Warm-up shortcut icon in the bottom right corner of the screen (when the warm-up shortcut switch is on),



Step 2: Click "Confirm" (or the device will start automatically when the timer runs out);



Step 3: The system is warming up, please wait...



√ Warm-up completed.

### 7.2.2 Automatic Quick cleaning Setting

Step 1: Go to: "Quick Menu" - "Service Menu" - "Machine Settings" - " Maintenance Settings";



Step 2: Set the interval of the desired quick rinse items (corresponding to the set time after the system is out of use). (i.e. rapid rinsing is carried out automatically) "Confirm";



Step 3: Click "Save" button to finish saving the above settings;



 $\sqrt{\ }$  Rapid rining setup complete.

# 7.3 Deep cleaning

#### 7.3.1 Brewer deep clean

Step 1: Click the shortcut menu icon at the top left of the screen to enter the Service Menu screen;



Step 2: Click on the screen " Deep Cleaning", then follow the prompts.



# 7.4 Manual cleaning

# 7.4.1 Beverage outlet Cleaning

Step 1: Remove the drink outlet, rinse and dry it and put it back.



### 7.4.2 Cleaning inside the machine

Step 1: Insert the key as shown and turn the key counterclockwise to open the coffee machine door;



Step 2: Remove the slag box and empty the waste water and slag;



Step 3: Clean the inside corners of the machine, first with a damp towel and then with a towel dry;



Step 4: Rinse the container with water and dry it with a towel;



Step 5: Put back the grounds container and close the coffee machine door;



Step 6: When cleaning at power on, the interface will pop up to confirm whether to empty the Dump Box or not, click "Not Empty" or "Emptied" accordingly.



# 7.4.3 Brewing system disassembly and cleaning

Step 1: Open the door of the coffee machine and remove the waste container by holding it by the handle;



Step 2: Push the clips inwards with your fingers as shown, then press down on the cartridge, then grasp the body of the brewer with your hand and remove the brewer outwards;



Step 3: Rinse the brewer with water and clean the brewer filter with a brush;



Step 4: Attach the brewer to the cartridge and push up on the cartridge (a "click" will indicate that it is in place);



Step 5: Put back the grounds container and close the coffee machine door;



Step 6: When the brewer installation is carried out in the boot state, the interface pops up the brewer self-test pop-up window, click 'self-test'.



#### 7.4.4 Beans, powder bin cleaning

Step 1: Open the coffee maker door, pull out the red handle and remove the bean bin:



Step 2: Clean and dry the bean compartments and put them back into the coffee machine.




# 7.5 Descaling

Step 1: Click the icon and shorcut at the top of the screen, then into the menu.



Step 2: Click "Descaling" on the screen, and then follow the interface prompts.



# 7.6 Storage

- Once the device is decommissioned, please observe the following placement conditions:
- Usage of the personnel authorized by the manufacturer;
- Relative air humidity max. 80 % rF.
- If the coffee machine and its accessories are transported at temperatures below 10°C, they must be left at room temperature for three hours after transport before being connected to the mains and started up. If this is not observed, there may be a risk of short circuits due to condensation or damage to electrical components.
- If a coffee machine in normal use needs to be stored or transported, when the ambient temperature is below 0°C, the water path must be cleared first.
- After the coffee machine has been out of service for an extended period of time (e.g. during company holidays), it must first be cleaned before being put into use again.

# 8 Liability and Warranty

# 8.1 User Responsibilities

- The user must ensure that the safety device is regularly maintained and inspected by Dr. Coffee's technical service personnel, its authorized personnel or other authorized personnel.
- Quality defects must be notified in writing to Dr. Coffee within 30 days. For hidden defects, this period is extended to 12 months after installation (work report, handover record).
- Parts involving safety, such as safety valves, safety thermostats, water boilers, etc., are not allowed to be repaired. Said parts must be replaced!
- These measures are carried out by the customer service technicians of Dr. Coffee or by the service partner when maintenance is performed.

## 8.2 Warranty and liability

- If personal injury or property damage is caused due to the following reasons, our company will not be liable for warranty and compensation:
- The machine is not being used correctly as specified.
- Incorrect installation, commissioning, operation, cleaning and maintenance and associated optional equipment.
- Maintenance intervals not respected.
- Continue to use this machine if safety devices and guards are damaged, incorrectly installed, or failed.
- Failure to comply with the instructions in the instruction manual regarding the preservation, installation, operation, use and maintenance of the machineSafety Instructions.
- The machine is not being used under normal conditions.
- Repairs are not performed correctly.
- Not use genuine parts from Dr. Coffee.
- Use a cleaner not recommended by Dr. Coffee.

- Damage caused by foreign objects, accident, vandalism and force majeure.
- Insert foreign objects into the machine or open the machine casing with foreign objects.
- The manufacturer assumes all possible liability for damages only if the prescribed service and maintenance intervals are observed and original spare parts ordered from the manufacturer or authorized suppliers are used.
- Dr.coffee's "General Terms of Business" apply.

# 9 Precautions for daily use and maintenance

- Please do not add water to the coffee bean hopper and powder hoppers;
- During the operation of the coffee machine, please do not open the door of the coffee machine forcibly, take out the grounds box, drip tray, water tank and other components;
- The external water tank can only be filled with pure water at room temperature, please do not add hot water or ice water;
- It is recommended to use coffee beans with medium roast or medium dark roast and not too oily. It is not recommended to use dark roasted or charcoal roasted and very oily coffee beans;
- If you need to change the type of coffee beans and powder, it is recommended to do calibration again;
- When the beverage flows out, please do not put your hand at the outlet of the coffee machine to avoid burns;
- When cleaning the machine, please do not use a brush or cleaning agent, so as not to damage the appearance of the coffee machine, please wipe it with a soft cloth dampened with water;
- Please do not exceed the MAX line for adding beans and powder hoppers to the bean hopper and powder hoppers. If there is no MAX line, fill it with 8 points.





- During the coffee making process, self-checking and resetting process, and automatic cleaning process, please do not cut off the power supply;
- According to the height of the coffee cup, adjust the height of the coffee outlet appropriately to avoid the splashing of beverages such as coffee and hot water;
- Every day after the machine is turned off and stopped for use, please empty the coffee grounds and waste water in the machine and clean it; if you use a machine with an external water supply, please do not use the machine after the external water source is cut off.
- Every day after the machine is turned off and stopped for use, please empty the coffee grounds and waste water in the machine and clean it;
- If you use a machine with an external water supply, please do not use the machine after the external water source is cut off.

